

Air Flow Factors


Model: PSS


Air Flow Measurements:


- 1. Place the velometer probe in each of the four positions marked in the following diagrams.
- 2. Record and average the velocity readings.
- 3. Calculate flow rate using the following equation.

Flow Rate: CFM = Factor x Average Velocity (FPM)

Note: Select and use the applicable factor from the following tables.







PSS Air Flow Factors (Side Blow)

P33 All Flow Factors (Side blow)			
Nominal Duct Size	Face or Ceiling Module Size		
	12 x 12 inches	24 x 24 inches	
6 x 6 inches	0.17	0.25	
8 x 8 inches		0.39	
10 x 10 inches		0.56	
12 x 12 inches		0.77	
6-inch diameter	0.21	0.22	
8-inch diameter		0.32	
10-inch diameter		0.45	
12-inch diameter		0.62	
14-inch diameter		0.82	
16-inch diameter		1.04	

PSS Air Flow Factors (Corner Blow)

Nominal Duct Size	Face or Ceiling Module Size	
	12 x 12 inches	24 x 24 inches
6 x 6 inches	0.19	0.46
8 x 8 inches		0.60
10 x 10 inches		0.77
12 x 12 inches		0.98
6-inch diameter	0.24	0.42
8-inch diameter		0.53
10-inch diameter	1	0.66
12-inch diameter	1	0.83
14-inch diameter		1.02
16-inch diameter		1.24

Notes: Same flow factors apply for the Alnor 6070, 6000, 2220, and 2220-A jet velometers.



Note: Refer to the Air Balancing Application Guide for more information about balancing air systems.