


DVIR UNIT DIMENSIONS



Exploded view of the DVIR Displacement Diffuser

DVIR UNIT DIMENSIONS

Model	Inlet Size	Nominal Unit Size	Unit Dimensions (inches)						
			A	B	C	E	F	G	H
DVIR	6 x 2	12 x 10	12	10	3 1/8	5 7/8	1 7/8	9 11/16	7 13/16
	6 x 2	12 x 12	12	12	3 1/8	5 7/8	1 7/8	9 11/16	9 13/16
	10 x 2	16 x 10	16	10	3 1/8	9 7/8	1 7/8	13 11/16	7 13/16
	10 x 2	16 x 12	16	12	3 1/8	9 7/8	1 7/8	13 11/16	9 13/16
	10 x 2	16 x 16	16	16	3 1/8	9 7/8	1 7/8	13 11/16	13 13/16
	10 x 2	16 x 24	16	24	3 1/8	9 7/8	1 7/8	13 11/16	21 13/16
	12 x 2	20 x 20	20	20	3 1/8	11 7/8	1 7/8	17 7/16	17 13/16
	14 x 2	24 x 12	24	12	3 1/8	13 7/8	1 7/8	21 11/16	9 13/16
	14 x 2	24 x 18	24	18	3 1/8	13 7/8	1 7/8	21 11/16	16
	14 x 2	24 x 24	24	24	3 1/8	13 7/8	1 7/8	21 11/16	21 13/16
	20 x 3	24 x 30	24	30	4	19 7/8	2 7/8	21 11/16	27 13/16
	20 x 3	24 x 36	24	36	4	19 7/8	2 7/8	21 11/16	33 13/16
	20 x 3	24 x 48	24	48	4	19 7/8	2 7/8	21 11/16	45 13/16
	20 x 3	30 x 24	30	24	4	19 7/8	2 7/8	27 11/16	21 13/16
	20 x 3	36 x 12	36	12	4	19 7/8	2 7/8	33 11/16	9 13/16
	20 x 3	36 x 24	36	24	4	19 7/8	2 7/8	33 11/16	21 13/16
	20 x 3	48 x 12	48	12	4	19 7/8	2 7/8	45 11/16	9 13/16
	20 x 3	48 x 24	48	24	4	19 7/8	2 7/8	45 11/16	21 13/16
24 x 3	60 x 24	60	24	4	23 7/8	2 7/8	57 11/16	21 13/16	

Redefine your comfort zone.™ | www.titus-hvac.com

T

DIMENSIONS

