



## INSTALLATION DETAILS


### REMOVING CENTER CONE



#### **OPTIONAL PATTERNS**



### ADJUSTING VERTICAL-TO-HORIZONTAL PATTERN / MODEL TDCA-FR




## **ACCESSORIES (OPTIONAL)**

## FIRE DAMPER WITH EXTENDED NECK

# **UL Listed Fusible Volume Adjustment Control**

Allows adjustment of fire damper blades to balance airflow. A hex key (by others) is required for adjustment.



Duct Size B	Extended Neck Height
6"x 6"	71/2"
9"x 9"	71/2"
12"x 12"	91/2"
15"x 15"	91/2"
18"x 18"	12½"
21"x 21"	12½"

Note: 21 x 21" size is not available with the TDCA-FR