


COIL/UNIT HANDING GUIDE

AIR to BACK


Unit and coil connections shown above are Right Hand. (RH) Inlet air to back



(LH) COIL CONNECTIONS

AIR to BACK

Unit and coil connections shown above are Left Hand. (LH) Inlet air to back



Vertical Largo Units are handed as "Inlet Air to Back"

Horizontal Largo Units are handed as "Inlet Air to Back"

TVB

THH

TVS

THB

TBL/TBS

TBH/TBV

TBM

Note: The industry standard to determine handing of an HVAC unit is with Inlet Air to Back.

*Inlet Air aka Return Air