



Overview

The FMS-2000C Critical Environment Controller ensures laboratory and healthcare settings are safe for all occupants by continuously verifying room pressure and airflow. The FMS-2000C can precisely control and monitor six parameters, which includes differential pressure, temperature, humidity, CO₂ levels, airflow, and air changes per hour. One controller can control or monitor up to four spaces simultaneously for any of the six parameters. This controller has a displayed pressure resolution down to 0.0001 in. W.C. or 0.0249 Pa and instantly updates as conditions change.

The FMS-2000C provides maximum room status awareness with color coded visual alarms both on screen and with the 360° Safety Halo illuminated edge. When the 360° Safety Halo is enabled, staff can easily monitor spaces on long corridors. You can put the audible alarm into snooze mode with one tap to the screen. There are two password protected access levels, one for administrators and one for restricted level users, such as nurses.


Features and benefits

Table 1: Features and benefits

Features	Benefits
Parameters	Controls and monitors up to six parameters across four rooms
Connectivity	18 available Input/Output (I/O) resources
Communications protocol	BACnet® MS/TP
Lighting	360° Safety Halo illuminated edge helps staff monitor spaces down long corridors
Design	Intuitive user interface allows for fast and easy set up
Display	5 in. (127 mm) high definition 720 pixels by 1280 pixels touchscreen display that works with rubber, nitrile, and latex gloves
Non-volatile memory	Saves users settings in case of a power outage
Password protection	Two access levels to prevent unauthorized access
Energy savings	Unoccupied mode reduces air and temperature changes
Home screen customization	The user can define the parameters displayed
Display override	Display measured values from the other monitored devices within the building automation system (BAS)
Global release	Offers a user interface that is translated into 17 languages

Components

Figure 1: Components overview



Note: Purchase of the FMS-2000C includes the display, controller, and from 0-4 pressure sensors. For more information, see Ordering information.

Table 2: FMS-2000C System diagram

Item	Component
1	FMS-2000 Display
2	Power supply
3	Controller
4	Door switch
5	Remote sensor

Applications

The following are appropriate environments for the FMS-2000C:

- Airborne infection isolation (All) rooms - negative pressure
- Protective environments (PE) isolation rooms - positive pressure
- All and PE rooms with an anteroom
- Operating rooms (ORs)
- Compounding pharmacies
- Pandemic preparedness rooms
- Intensive care units
- Laboratories and vivariums
- Burn units
- Bronchoscopy suites
- Mortuary preparation rooms and autopsy rooms
- Data centers
- Laundry areas
- Indoor growing facilities
- Crime labs

See Table 3: Product guide to help you determine whether your application requires the FMS-2000C Critical Environment Controller or the FMS-2000M Critical Environment Monitor.

Table 3: Product guide

Features and capabilities	FMS-2000C	FMS-2000M
Differential pressure control	Yes	No
Differential pressure monitoring	Yes	Yes
Volumetric air flow	Yes	Yes ¹
Volumetric offset control	Yes	No
Temperature control	Yes	No
Temperature monitoring	Yes	Yes ¹
External thermostat integration	Yes	No
Relative humidity	Yes	Yes ¹
Air change rate	Yes	Yes ¹
CO ₂ concentration	Yes	Yes ¹
BACnet MS/TP communications	Yes	Yes
Metasys N2 communications	No	No
Lon communications	No	No
Door switch support	Yes	Yes
Occupancy switch support	Yes	No
Override switch support	Yes	No
Analog input override	Yes	No
Analog output override	Yes	No
Universal analog inputs	4	0
Universal analog outputs	4	0
Digital inputs	4	4 ²
Relay outputs	4	0
Thermistor inputs	2	0
Works with CMS-1655 and CMS-2000 Central Monitoring Station	Yes	No

¹ Shared through BACnet by writing to the appropriate AV.

² Up to four digital inputs. One input on each pressure sensor. For door switch use only.

Ordering information

Table 4: Ordering information

Features	Code letter or number and description	Product code number example: FMS2C-BT20
Unit	FMS = Flow Monitor Station (FMS)	FMS
Series	2 = 2000 C = Controller	2C
Communications protocol	B = BACnet MS/TP	B
Mounting style	T = Thin	T
Remote sensor ¹	0 = No remote sensors 1 = One remote sensor 2 = Two remote sensors 3 = Three remote sensors 4 = Four remote sensors	2
ISO power	0 = 24 V power supply not included	0

¹ If you plan to use third-party sensors, select 0.

Mounting hardware

All FMS-2000 Thin mount displays require one of the following mounting options for installation:

Table 5: Mounting hardware

Ordering code	Description	Dimensions (H X W X D)
RFINMT-2	Rough in Box for new construction where walls are not installed	4.84 in. x 3.18 in. x 1.5 in. (122.94 mm x 80.77 mm x 38.1 mm)
RTROMT-2	Retrofit Ring with walls already installed	6.06 in x 4.311 in. x 0.548 in. (153.924 mm x 109.499 mm x 13.919 mm)

Available transformers

The following table lists the transformers that meet the requirements for the FMS-2000C Critical Environment Controller.

Table 6: Y65T and Y63T transformers

Ordering code	Primary voltage (VAC)	Secondary voltage (VAC)	Primary connection	Secondary Connection	Mounting	Agency requirement
Y65T31-0	120/208/240	24	Male fitting 8 in. primary leads	Three screw terminals (one is blind)	Foot 4 in. x 4 in. plate	cULus Class 2
Y65T31-0G	120/208/240	24	Male fitting 8 in. primary leads	Three screw terminals (one is blind)	Foot 4 in. x 4 in. plate	cULus Class 2
Y65T42-0	120/208/240	24	Common male fitting 8 in. primary leads	Common male fitting 8 in. secondary leads	Hub 4 in. x 4 in. plate	cULus Class 2
Y65T54-0	120/208/240	24	8 in. primary leads	8 in. secondary leads	Foot-skeleton	cULus Class 2
Y63T22-0	120/208/240	24	End bell hole 8 in. primary leads	End bell hole 8 in. secondary leads	4 in. x 4 in.	cULus Class 2

Note: Some applications may require a plenum rated box. Do not power more than one device with a single transformer.

Technical specifications

Table 6: Technical specifications

Specification	Description	
Intended use	Indoor use	
Overvoltage category	II	
Altitude	Up to 2000 m (6562 ft)	
Pressure range	± 0.2500 in. W.C. (± 62.27 Pa)	
Alarm range	± 0.2500 in. W.C. (± 62.27 Pa)	
Display range	± 0.2500 in. W.C. (± 62.27 Pa)	
Accuracy	± 0.5% full scale	
Air flow sensor type	Digital differential pressure features no offset, zero drift and is hysteresis free	
Flow control resolution	± 0.0010 in. W.C. (± 0.2491 Pa)	
Displayed pressure resolution	± 0.0001 in. W.C. (± 0.0249 Pa)	
Control capability	Up to 4 independent spaces	
I/O Resources	4 universal inputs (0 mA – 20 mA, 4 mA – 20 mA, 0 VDC – 5 VDC, 0 VDC – 10 VDC, 1 VDC – 5 VDC, 2 VDC – 10 VDC) 2 thermistor inputs (NTC Type 2 or 3, 10K at 77° F) 4 digital inputs (active-high or active-low) 4 universal outputs (0 mA – 20 mA, 4 mA – 20 mA, 0 VDC – 5 VDC, 0 VDC – 10 VDC, 1 VDC – 5 VDC, 2 VDC – 10 VDC) 4 relay outputs (NO or NC contacts 1A at 24 VDC)	
Operating temperature	32°F to 104°F (0°C to 40°C)	
Operating humidity	10% to 95% relative humidity, non-condensing	
Mounting	Thin mount for shallow wall cavities	
Alarm indication	Safety Halo color coded visual, audible alarm	
Alarm silence	Touchscreen, auto-reset	
Password protection	Up to 50 user passwords with 2 access levels (administrator and restricted)	
Communications protocol	BACnet® MS/TP (to BAS) 76.8k, 38.4k, 19.2k, 9600 baud	
Power requirement	24 VAC (nominal, 21.6 VAC minimum/26.4 VAC maximum), 50/60 Hz 30 VA power supply, Class 2, Limited Energy, LPS or minimum power 30 VA transformer.	
Power consumption	30 VA maximum	
Pollution degree	2	
Display resolution	720 pixels x 1280 pixels	
Pluggable screw terminal blocks	18 AWG to 22 AWG (1.0 mm to 0.6 mm diameter)	
Display dimensions (height x width x depth)	5.3 in. x 3.5 in. x 1.17 in. (134.62 mm x 88.9 mm x 29.72 mm)	
Mounted depth	0.58 in. (14.73 mm)	
Controller dimensions (height x width x depth)	6.56 in. x 5.5 in. x 1.88 in. (166.62 mm x 139.7 mm x 47.75 mm)	
Compliance   	United States	UL Listed (E515759) to UL 61010-1; FCC 47CFR Part 15; BTL Listed (BTL-30774)
	Canada	cUL Listed (E515759) to CAN/CSA C22.2 NO. 61010-1; ICES-003
	Europe (CE)	Low Voltage Directive [2014/35/EU] per EN 61010-1 EMC Directive [2014/30/EU] per EN 61326-1 + EN 55011
	United Kingdom (UKCA)	Electrical Equipment (Safety) Regulations per EN 61010-1 EMC Regulations per EN 61326-1 + EN 55011
	International Standards	Product fulfills the requirements of IEC 61010-1 as recognized by national or regional authorities.
	BACnet International (BTL)	BACnet Testing Laboratories (BTL) 135-2021 Listed BACnet Application Specific Controller (B-ASC)

North American Emissions Compliance

United States

This equipment has been tested and found to comply with the limits for a Class A digital device pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when this equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area may cause harmful interference, in which case users will be required to correct the interference at their own expense.

Canada

This Class (A) digital apparatus meets all the requirements of the Canadian Interference-Causing Equipment Regulations. Cet appareil numérique de la Classe (A) respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.

Repair information

If you purchased a service agreement, contact your Titus representative for a replacement unit. If you do not have a service agreement, contact tu@titus-hvac.com.

Patents

Patents: <https://jciapat.com>

Software terms

Use of the software that is in (or constitutes) this product, or access to the cloud, or hosted services applicable to this product, if any, is subject to applicable end-user license, open-source software information and other terms set forth at www.johnsoncontrols.com/techterms. Your use of this product constitutes an agreement to such terms.

Product warranty

This product is covered by a limited warranty. Contact your representative for more details.

Contact information

Contact your local Titus representative

Contact Support: Call (+1) 972-212-4800 or email tu@titus-hvac.com